





- | | |
|-----------------|-------------------|
| (GB) Attention | (SE) Uppmärksamma |
| (DE) Achtung | (FI) Huomaa |
| (FR) Attention | (NL) Opgelet |
| (ES) Atención | (RU) Внимание |
| (IT) Attenzione | (CN) 注意 |
| | (PL) Uwaga |



- | | |
|------------------|------------------|
| (GB) Dismounting | (SE) Demontering |
| (DE) Demontage | (FI) Irrotus |
| (FR) Démontage | (NL) Demontage |
| (ES) Desmontaje | (RU) Демонтаж |
| (IT) Smontaggio | (CN) 卸载 |
| | (PL) Demontaż |



- | | |
|----------------|----------------|
| (GB) Mounting | (SE) Montering |
| (DE) Montage | (FI) Asennus |
| (FR) Montage | (NL) Montage |
| (ES) Montaje | (RU) Монтаж |
| (IT) Montaggio | (CN) 安装 |
| | (PL) Montaż |




- | | |
|----------------|---------------|
| (GB) Direction | (SE) Riktning |
| (DE) Richtung | (FI) Suunta |
| (FR) Sens | (NL) Richting |
| (ES) Dirección | (RU) Внимание |
| (IT) Senso | (CN) 方向 |
| | (PL) Kierunek |

MI-538835

- (GB) Mounting instruction
(DE) Montageanleitung
(FR) Instructions de montage
(ES) Instrucción de montaje
(IT) Istruzioni di montaggio
(SE) Monteringsinstruktion
(FI) Asennusohjeet
(NL) Montage instructie
(RU) Инструкция по монтажу
(CN) 安装说明
(PL) Instrukcja montażu



MI-538835




- (GB) Scrap the component
(DE) Komponente nicht wieder verwenden
(FR) Jeter le composant

- (ES) Desechar el componente
(IT) Componente di scarto
(SE) Skrota komponenten
(FI) Heitä tämä osa pois
(NL) Verwijder het onderdeel
- (RU) Внимательно осмотрите компонент
(CN) 拆毁配件
(PL) Wyrzucić element



- (GB) Reuse the component
(DE) Komponente kann wiederverwendet werden
(FR) Réutiliser le composant

- (ES) Reutilizar el componente
(IT) Riutilizzo del componente
(SE) Återanvänd komponenten
(FI) Käytä tämä osa uudelleen
(NL) Hergebruik het onderdeel
- (RU) Используйте повторно в случае годности
(CN) 重用配件
(PL) Ponownie użyć element



- (GB) SKF Wheel bearing kit
(DE) SKF Radlagersatz
(FR) Kit de roulement de roue SKF
(ES) Kit de rodamiento de rueda SKF

- (IT) SKF kit cuscinetto ruote
(SE) SKF Hjullagersats
(FI) SKF Pyöränlaakerisarja
(NL) SKF Wiellager set
(RU) SKF Ремонтный комплект подшипника ступицы колеса
(CN) SKF 轮毂轴承修理包
(PL) Zestaw naprawczy SKF do koła

